




EPO-FLEX® MER II (Mechanical Equipment Room)

EPO-FLEX MER II (MECHANICAL EQUIPMENT ROOM) SYSTEM combines EPO-FLEX crack bridging and waterproofing capabilities with a chemically resistant topcoat and an optional wearcourse of EPO-FLEX broadcast to excess with hard aggregate would provide increased wear, impact, and abrasion resistance. EPO-FLEX achieves flexibility without the use of plasticizers or other additives which can separate or migrate as the system ages. This means that the product remains flexible and continues to function for many years. Fiberglass scrim may be incorporated into the system to add tensile strength.



90 Mil System

Advantages

- Bridges hairline cracks, thereby aiding in suppression of cracks reflecting through the system due to substrate movement
- Color options
- Durable, Slip resistant
- Waterproof
- Chemical and stain resistant
- Fiberglass scrim optional for maximum tensile strength
- VOC compliant, Low odor

Uses

- Mechanical Equipment Room
- Mezzanines
- Clean Rooms
- Lockers Rooms and Showers
- Computer Rooms

Typical Physical Properties of 3555

| | |
|--|-------------------------------------|
| VOC (Volatile Organic Content) EPA method 24 SCAQMD Method 304 | Compliant Compliant |
| Hardness, Shore D ASTM D 2240 | 50/40 |
| Tensile Strength ASTM D 412 | 1,700 psi |
| Elongation ASTM D 412 | 80% |
| Adhesion ACI 503R | 350 psi 100% concrete failure |
| Abrasion Resistance ASTM D 4060, CS-17 Wheel, 1,000 cycles | 100 mgs lost |
| Flammability | Self-Extinguishing over concrete |
| Thermal Cycling ASTM C 884 (24 hours, -21°C to 25°C) | No Cracking |

ASTM C = Mortar system
ASTM D = Resin only

Installation

General Polymers materials shall only be installed by approved contractors. The following information is to be used as a guideline for the installation of the EPO-FLEX MER II (MECHANICAL EQUIPMENT ROOM) SYSTEM. Contact the Technical Service Department for assistance prior to application.

Surface Preparation - General

General Polymers systems can be applied to a variety of substrates, if the substrate is properly prepared. Preparation of surfaces other than concrete will depend on the type of substrate, such as wood, concrete block, quarry tile, etc. Should there be any questions regarding a specific substrate or condition, please contact the Technical Service Department prior to starting the project. Refer to Surface Preparation (Form G-1).

Surface Preparation - Concrete

Concrete surfaces shall be abrasive blasted to remove all surface contaminants and laitance. The prepared concrete shall have a surface profile equal to CSP 3-5. Refer to Form-G-1.

After initial preparation has occurred, inspect the concrete for bug holes, voids, fins and other imperfections. Protrusions shall be ground smooth while voids shall be filled with a system compatible filler. For recommendations, consult the Technical Service Department.

Temperature

Throughout the application process, substrate temperature should be 60°F - 90°F. Substrate temperature must be at least 5°F above the dew point. Applications on concrete substrate should occur while temperature is falling to lessen offgassing. The material should not be applied in direct sunlight, if possible.

Application Information

| Material | Mix Ratio | Theoretical Coverage Per Coat Concrete | Packaging |
|---|-----------|---|-------------------------|
| Primer 3579 | 2:1 | 250 sq. ft. / gal | 3 or 15 gals |
| Membrane 3555 | 1:1 | 80 sq. ft. / gal | 2 or 10 gals |
| Wearcourse 3555 Dry Silica Sand (30mesh) or Other Hard Aggregate | 1:1 | 130 sq. ft. / gal .25 lbs. / sq. ft. | 2 or 10 gals 100 lbs |
| Seal Coat 3744 | 2:1 | 100-150 sq. ft. / gal | 3 or 15 gals |

Primer

Mixing and Application

1. Premix 3579A (resin) using a low speed drill and Jiffy blade. Mix for one minute and until uniform, exercising caution not to introduce air into the material.
2. Add 2 parts 3579A (resin) to 1 part 3579B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes and until uniform. To insure proper system cure and performance, strictly follow mix ratio recommendations.
3. 3579 may be applied via spray, roller or brush. Apply 5-8 mils, evenly, with no puddles. Coverage will vary depending upon porosity of the substrate and surface texture.
4. Wait until primer is tacky (usually 1 hour minimum), before applying the slurry. If primer is not going to be topped within open time, broadcast silica sand into resin lightly but uniformly and allow to cure overnight.

Membrane

Mixing and Application - If priming is done to reduce outgassing, allow to cure overnight before topping

1. Premix 3555A (resin) using a low speed drill and Jiffy blade. Mix for one minute and until uniform, exercising caution not to whip air into the material.
2. Add 1 part 3555A (resin) to 1 part 3555B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes and until uniform.
3. Immediately pour the mixed material onto the substrate and pull out using a 1/4" or 1/8" v-notched squeegee to yield 20 mils WFT and cross roll with a 3/8" nap roller. Readings must be taken continuously during application with a wet mil gauge to verify material is being applied at the proper thickness. Allow to cure overnight at 73°F surface temperature. Material cures slower at lower temperatures.
4. After the membrane is cured, check for surface blush. Remove any blush with detergent wash prior to applying wearcourse.

Wearcourse

Mixing and Application

1. Premix 3555A (resin) using a low speed drill and Jiffy blade. Mix for one minute and until uniform, exercising caution not to whip air into the material.
2. Add 1 part 3555A (resin) to 1 part 3555B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes and until uniform.
3. Immediately pour the mixed material onto the substrate and pull out using a 1/4" or 1/8" v-notched squeegee to yield 12 mils WFT and cross roll with a 3/8" nap roller. Readings must be taken continuously during application with a wet mil gauge to verify material is being applied at the proper thickness. Material cures slower at lower temperatures.
4. Broadcast Dry Silica Sand (30 mesh) or other Hard Aggregate to excess into wet material so no wet material is visible. Aggregate should be broadcast within one (1) hour of liquid application to ensure they are properly seated.
5. Allow to cure (Cure times vary depending on environmental conditions), sweep off excess aggregate with a clean, stiff bristled broom. Clean aggregate can be saved for future use. All imperfections such as high spots should be smoothed before the application of the seal coat.

NOTE: The floors finished appearance depends on the manner in which the aggregate has been applied. In grass seed like fashion, allow the aggregate to fall after being thrown upward and out. **DO NOT THROW DOWNWARD AT A SHARP ANGLE USING FORCE.**

Seal Coat

Mixing and Application

1. Premix 3744A (resin) using a low speed drill and Jiffy blade. Mix for one minute and until uniform, exercising caution not to introduce air into the material.
2. Add 2 parts 3744A (resin) to 1 part 3744B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes and until uniform. To insure proper system cure and performance, strictly follow mix ratio recommendations.
3. Apply 3744 using a flat trowel or squeegee and backroll with a 1/4" nap roller at a spread rate of 100-150 sq. ft. per gallon, evenly, with no puddles making sure of uniform coverage. **Take care not to puddle materials and insure even coverage.**
4. Allow to cure 24 hours minimum before opening to traffic.

Epoxy materials will appear to be cured and "dry to touch" prior to full chemical cross linking. Allow 3744 to cure for 2-3 days prior to exposure to water or other chemicals for best performance.

Cleanup

Clean up mixing and application equipment immediately after use. Use toluene or xylene. Observe all fire and health precautions when handling or storing solvents.

Safety

Refer to the MSDS sheet before use. All applicable federal, state, local and particular plant safety guidelines must be followed during the handling and installation and cure of these materials.

Safe and proper disposal of excess materials shall be done in accordance with applicable federal, state, and local codes.

Material Storage

Store materials in a temperature controlled environment (50°F - 90°F) and out of direct sunlight.

Keep resins, hardeners, and solvents separated from each other and away from sources of ignition. One year shelf life is expected for products stored between 50°F - 90°F.

Maintenance

Occasional inspection of the installed material and spot repair can prolong system life. For specific information, contact the Technical Service Department.

Shipping

- Destinations East of the Rocky Mountains are shipped F.O.B. Cincinnati, Ohio.
- Destinations West of the Rocky Mountains are shipped F.O.B. Victorville, California.

For specific information relating to international shipments, contact your local sales representative.

Disclaimer

The information and recommendations set forth in this document are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product(s) offered at the time of publication. Published technical data and instructions are subject to change without notice.

Consult www.generalpolymers.com to obtain the most recent Product Data information and Application instructions.

Warranty

The Sherwin-Williams Company warrants our products to be free of manufacturing defects in accord with applicable Sherwin-Williams quality control procedures. Liability for products proven defective, if any, is limited to replacement of the defective product or the refund of the purchase price paid for the defective product as determined by Sherwin-Williams, NO OTHER WARRANTY OR GUARANTEE OF ANY KIND IS MADE BY SHERWIN-WILLIAMS, EXPRESSED OR IMPLIED, STATUTORY, BY OPERATION OF LAW OR OTHERWISE, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

